

i dog
My pet loves music, too!
mini




USER'S GUIDE

"Feed" I-DOG Music

To keep I-DOG satisfied and healthy, be sure to "feed" (play) him lots of music!

If I-DOG is hungry and needs more music from you, his center LED will slowly pulsate yellow-green-yellow-green. The sequence will blink faster as he gets hungrier. When you see this happen, "feed" him some music!

If I-DOG is lonely and needs more attention from you, his center LED will slowly pulsate red-orange-red-orange. The sequence will blink faster as he gets more desperate for your attention. When you see this happen, press his Nose Button a few times to show him attention!



Middle LED


Thank you for purchasing I-DOG. Be sure to read and follow all instructions carefully before using this product.

I-DOG moves and grooves, and displays light animations to the beat of the music he hears. This dog's got music skills. Turn off your music and he'll play 12 of his own riffs. I-DOG loves to show you his moods - if your music's making him mellow, turn up your tunes!


Requires 3 x 1.5V "AAA" or LR03 size alkaline batteries (not included). Phillips/cross head screwdriver (not included) needed to insert batteries.

How to "Feed" I-DOG

I-DOG listens to music through its built-in Microphone. Simply place him near a speaker, where the volume is at a higher level, and watch him react! Observe his funky light patterns that pulse to the music he hears.



Getting To Know I-DOG



Which I-DOG do you have?

Rock - Plays rock riffs and glows red.	Hip Hop - Plays hip hop beats and glows yellow.
Dance - Plays dance tunes and glows green.	Pop - Plays pop songs and glows orange.

Moods

When music is not being played, double-click the Nose Button and I-DOG will show you a mood.

I-DOG changes his moods based on how much love and attention you give him (or don't give him) and how much music you've played for him. You can tell what kind of mood he's in from listening to the sounds he makes and the LED light patterns he displays.

When you're done "feeding" I-DOG (no music is playing), double-click the Nose Button and pay attention to the light patterns I-DOG displays to determine what mood he's in.

EXCITED

This means that you're "feeding" I-DOG lots of music and giving him a lot of love and attention. You're pressing his nose so much he's excited. When you double-click his nose, he'll play excited music and show you the following light sequence:



NOTE - this light sequence moves quickly

To Install Batteries

To begin playing with I-DOG, you must first install the batteries.

Using a Phillips/cross head screwdriver, loosen screw in battery compartment cover (screw stays attached to cover) on the center of his tummy. Insert 3 x 1.5V "AAA" or LRO3 size alkaline batteries (not included) in the battery compartment and in the cover. Replace cover and tighten screw.

CAUTION:

1. As with all small batteries, the batteries used with this toy should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone (202) 625-3333 collect. In other countries, have the doctor call your local poison control center.
2. Make sure the batteries are inserted correctly and always follow the toy and battery manufacturers' instructions;
3. Do not mix old batteries and new batteries or alkaline, standard (carbon zinc) or rechargeable (nickel-cadmium) batteries.

HAPPY

This means that you're "feeding" I-DOG enough music and giving him the right amount of love and attention. When you double-click his nose, he'll play happy music and show you the following light sequence:




LONELY

This means that I-DOG really needs to be "fed" more music and shown more love and attention! Be sure to press his nose and play him some more music! When you double-click his nose, he'll play lonely music and show you the following light sequence:



SAD

This means that you've left I-DOG alone for too long. He needs more music and attention soon, or he may get sick! When you double-click his nose, he'll play sad music and show you the following light sequence:



IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference.
Batteries should be replaced by an adult.

CAUTION:

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert item correctly by matching the + and - polarity markings.
2. Do not mix old and new batteries or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short-circuit the supply terminals.
6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
7. RECHARGEABLE BATTERIES: Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.
8. As with all small items, these batteries should be kept away from children. If swallowed, seek medical attention immediately.

Important Tips

1. If you are not playing with I-DOG, please remember to press and hold down the Nose Button for at least 5 seconds to turn him OFF. This will help conserve battery life.
2. If you do not interact with I-DOG for one hour, he will automatically shut off.
3. I-DOG may react to other sounds or noises that he hears, other than music.

Troubleshooting Guide

What to do if:

I-DOG Freezes Up


Press the Reset Button using a pen tip.

I-DOG Begins Acting Erratically

Change the batteries.

Getting Started

1. Turn I-DOG ON by pressing the Nose Button. I-DOG will display a special LED light animation and sound to show you that he's awake and ready to play!
2. When you are finished playing with I-DOG, press and hold down the Nose Button for at least 5 seconds to turn him OFF. I-DOG will display an LED animation and make a sound to signal that he's going to sleep.



Give I-DOG Lots of Love and Attention

To keep I-DOG happy, be sure to give him plenty of love and attention. Press his Nose Button and he will make a scratching sound effect while displaying a spinning LED light pattern. Double-click his Nose Button quickly and repeatedly to hear music and see LED patterns that represent what mood I-DOG currently has. If I-DOG whines instead of playing a musical riff in return, that means he has become sick from not getting enough music and attention.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Product and colors may vary.



© 2005 Hasbro. All rights reserved.
Hasbro Canada, 2350 de la Province, Longueuil, QC, Canada J4G 1G2.



恒景電子遊戲有限公司
ETERNITY ELECTRONIC GAMES LIMITED

地址: 新界葵青葵芳路223號
新都會廣場1座31樓3105-3112室
電話: 2310 9011